MapmyIndia™

Hardware User Manual

Contents

1.Operation Instructions 3
1.1 Introduction 3
1.2 Main Menu 3
1.3 Application list 5
1.4 Settings 6
1.4.1 Wireless & networks 6
1.4.2 Call settings 8
1.4.3 Sound 9
1.4.4 Display 9
1.4.5 Location & security 10
1.4.6 Applications 10
1.4.7 Accounts & sync 11
1.4.8 Privacy 12
1.4.9 SD card & phone storage 12
1.4.10 Search 13
1.4.11 Language & keyboard 13
1.4.12 Voice input & output 14
1.4.13 Accessibility 14
1.4.14 Date & time 15
1.4.15 About phone 15
1.5 Phone 16
1.6 Messaging 17
1.7 Gallery 18
1.8 Music 19
1.9 Media player 19
1.10 Browser 20
1.11 Bluetooth 20

1. Operation Instructions

1.1 Introduction.







1	LED	Red during charging, green after fully charged.
2	LCD	5 inch LCD, resolution 800*480
3	Home	Return to main interface
4	Menu	Enter into menu interface
5	Back	Return to previous menu
6	Power button	Power on (press for 2S) / Power off (press for3S) / Lock up the screen (single click)

7	Volume+	Increase volume
8	Volume-	Decrease volume
9	Push to talk	Customized services
10	Earphone jack	Connect for stereo earphone
11	SIM Slot	Insert 3G/GSM card
12	USB port	Mini 5pin USB
13	Micro SD Card Slot	Support Micro SD card

1.2 Main Menu



Slide down to mute

Slide up to unlock

	GPS Signal		WIFI Signal		GSM Signal
	Battery Capacity	1:09 PM	Time	Google	Google Search
	Phone		Application Menu		Browser
3G	3G data Signal		USB Connected		





Operator

Missed Call



Missed messages

1.3 Application list

Click icon into applications menu:



Note: Long pressing an application icon can add shortcut to the desktop.

1.4 Settings

1.4.1 Wireless & networks

Click

icon, then select wireless & network:



- **Wi-Fi settings**

Turn on Wi-Fi . Device can search for nearby Wi-Fi network automatically and display related network information. Choose the WIFI router.

If it displays locked as , you need type password to connect:

Note: long press input area can change input method as follows:



In Wi-Fi settings screen, press “MENU” button, select advanced options:

You can select Wi-Fi sleep policy and set static IP:



- **Mobile network settings**



Enable/Disable Data

data services or not during roaming

APN

Set a network operator

1.4.2 Call settings



Select voicemail service carrier



Input your carrier voicemail number

Other call setting

1.4.3 Sound

- Sound settings

Click **Volume** to set volume

Ring tone setting

Media volume setting

Alarm volume setting

1.4.4 Display



Brightness — Brightness setting

Auto-rotate screen — Open/close auto-rotate

Animation
All window animations are shown — Animation effects

Screen timeout
Adjust the delay before the screen automatically turns off — Lock screen up time

1.4.4 Location & security

- **Set up screen lock**

Click **Set up screen lock** to set screen lock

None	Remove screen lock
Pattern	Draw pattern to unlock screen
PIN	Use PIN code to unlock screen
Password	Use a password to unlock screen

Note: Pin code is a password for SIM card. If you operate wrongly over time, the SIM card will be locked.

1.4.5 Applications

- **Application settings**

Click **Applications** into application settings interface:

Note: If choose unknown sources , the system will allow installation of non-Market applications.

- **Manage applications**

Click Manage applications:



In the interface, you can see application details and uninstalled programs from the system completely.

1.4.6 Accounts & sync

Click Accounts & sync, and then click Add account add :

For example: Google account. You can create or sign in a Google account.



Note: when you add an account successfully, the calendar Calendar can show current date.

1.4.7 Privacy

Click Factory data reset → Reset phone icon:


10:15 AM
Factory data reset
This will erase all data from your phone, including:
• Your Google account
• System and application data and settings
• Downloaded applications
It will not erase:
• Current system software and bundled applications
• SD card files, such as music or photos
Reset phone
10:19 AM
Factory data reset
Erase all of your personal information and any downloaded applications? It is impossible to reverse this action!
Erase everything

Click Erase everything icon, and press power button at the same time until the device restart automatically.

Note: this will erase all your own data (Internal Memory) in device, please save as backup if needed.

1.4.8 SD card & phone storage

Click SD card & phone storage to choose mount and unmount micro SD card:



Note: Before pull out micro SD card, please click Unmount SD card first for data safety. After insert micro SD card, please click Mount SD card to install it.

1.4.9 Search

Click Search to set the google search content:



Return desktop to search related content.

1.4.10 Language & keyboard

- **Select language**

Click Select language to set native language.



Select a language and then click return button to save the result.

1.4.11 Voice input & output

Please make sure the internet is connected. You can install the application from Google market.

When the android keyboard displays as icon, click icon to say what you want.

1.4.12 Accessibility



Click icon to set shortcut key.

1.4.13 Date & time

Click Date & time to set date and time:



Set date	Set current date
Select time zone	Select time zone for your location
Set time	Set current time
Use 24-hour format	24/12 hour format
Select date format	Select right date format

1.4.14 About phone

You can check the device information:



1.5 Phone

Click

icon into phone interface:



Phone call

Call log information

Contact number

My favorites

- **Outgoing calls**

Click cursor position to type phone number:



Click

icon to open the keyboard

Hang up

keyboard

- **Incoming call**



1.6 Messaging

Click icon to view messages:

Write a new message

SMS received

- **Edit a message**

Click New message to write a new message:

Open the interface | Input a receiver | Enter the message text | Messages list

1.7 Gallery

Click icon to browse picture:

Note: It needs some time to read all pictures for the first operation. Press a picture 2S for more advance options.

1.8 Music

Click

icon to play music:





1.9 Media player

Click

icon to play video:



external_sd →Micro SD card

1.10Browser

Click

icon to browse web page:



- Make sure the internet is connected.
- You can use 3G /GPRS /WIFI network.
- Click MENU button for more operation.

1.11 Bluetooth

Click

icon, then select wireless & network.

- Turn on Bluetooth ..Then Click in Bluetooth settings to set up Bluetooth pairing.

- Click on Discoverable. This will enable other Bluetooth devices to find Carpad 5.



Click Scan for devices to look for Bluetooth devices

- Click on chosen discovered mobile for establishing pairing.

2. Warnings and Precautions

This section contains important information about how to use the device safely. Read the information carefully before using your device.

Medical Device

Follow rules and regulations set forth by hospitals and health care facilities. Do not use your device when using the device is prohibited.

Pacemaker manufacturers recommend that a certain distance be maintained between a device and a pacemaker to prevent potential interference. If you are using a pacemaker, use the device on the opposite side of the pacemaker and do not carry the device in your front pocket.

Prevention of Hearing Damage

Using a headset at high volume can damage your hearing. To reduce the risk of damage to hearing, lower the headset volume to a safe and comfortable level.

Potentially Explosive Atmosphere

Power off your device in any area with a potentially explosive atmosphere, and comply with all signs and instructions. Areas that may have potentially explosive atmospheres include the areas where you would normally be advised to turn off your vehicle engine. Triggering of sparks in such areas could cause an explosion or a fire, resulting in bodily injuries or even deaths. Do not power on your device at refueling points such as service stations. Comply with restrictions on the use of radio equipment in fuel depots, storage, and distribution areas, and chemical plants. In addition, adhere to restrictions in areas where blasting operations are in progress. Such locations include areas below the deck on boats, chemical transfer or storage facilities, and areas where the air contains chemicals or particles such as grain, dust, or metal powders.

Traffic Security

Do not talk on the device while driving and use hand-free accessories if necessary. In addition, if using the device while driving a vehicle, comply with local laws and regulations.

In a motor vehicle, do not place the device over the air bag or in the air bag deployment area. Otherwise, the device may hurt you owing to the strong force when the air bag inflates.

Do not use your device while flying in an aircraft and power off your device before boarding an aircraft. Using wireless devices in an aircraft may cause danger to the operation of the aircraft and disrupt the wireless telephone network.

Operating Environment

CAUTION :**Considering the hot weather conditions in India especially during summer,when car is parked which means AC in car is also not operative, the temperature inside in car easily goes above 55C.Keeping the device at such high temperature for prolong period of time may effect the device and it's battery. Hence it is strictly advisable to take the device along with you in such conditions.**

Do not use or charge the device in dusty, damp and dirty places or places with magnetic fields. Otherwise, it may result in a malfunction of the circuit. On a stormy day with thunder, do not use your device when it is being charged, to prevent any danger caused by lighting.

While using the device, observe the local laws and regulations, and respect others' privacy and legal rights.

Accessories

Using the accessories delivered only by the manufacturer. Using accessories of other manufacturers or vendors with this device model may invalidate any approval or warranty applicable to the device, and result in the non-operation of the device, and cause danger.

Battery and Charger

The battery can be charged and discharged hundreds of times before it eventually wears out. When the standby time and the talk time are shorter than the normal time, replace the battery.

Do not connect two poles of the battery with conductors, such as metal materials, Keys, or jewelries. Otherwise, the battery may be short-circuited and may cause injuries and burns on your body.

Do not disassemble the battery or solder the battery poles. Otherwise, it may lead to electrolyte leakage, overheating, fire, or explosion.

If there is a case of battery deformation, color change, or abnormal heating while you charge or store the battery, remove the battery immediately and stop using it. Otherwise, it may lead to battery leakage, overheating explosion, or fire.

If the power cable is damaged (for example, the cord is exposed or broken), or the plug loosens, stop using the cable at once. Otherwise, it may lead to an electric shock, a short circuit of the charger, or a fire.

Do not dispose of batteries in fire as they may explode. Batteries may also explode if damaged.

Danger of explosion if battery is incorrectly replaced. Recycle or dispose of used battery according to the local regulations or reference instruction supplied with your device.

Emergency Call

You can use your device for emergency calls in the service area. The connection, however, cannot be guaranteed in all conditions. You should not rely solely on the device for essential communications.